



### **FLEXAMAT<sup>®</sup> INFORMATION**

Manufacturer: Motz Enterprises, Inc.  
 Product Name: Flexamat  
 Address: 3153 Madison Road  
 Cincinnati, Ohio 45209  
 Telephone: 513-772-6689  
 Email: [Info@Flexamat.com](mailto:Info@Flexamat.com)  
 Website: [www.Flexamat.com](http://www.Flexamat.com)

### **CONSTRUCTION NOTES:**

1. GRADE A UNIFORM SUBGRADE. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OR DEBRIS OF ANY KIND. THE PREPARED SURFACE.
2. INSTALL 10-OZ GEOTEXTILE FABRIC OVER GRADED SUBGRADE.
3. INSTALL 12" OF #3 Stone BASE OVER GEOTEXTILE FABRIC.
4. INSTALL BI-AX- GEOGRID OVER #3 STONE BASE.
5. INSTALL 10" OF GRADED AGGREGATE BASE STONE OVER GEOGRID.
6. INSTALL FLEXAMAT OVER GRADED AGGREGATE BASE STONE.
7. FILL FELXAMAT WITH 1"-2" OF CRUSHED/ANGULAR AGGREGATE BASE STONE OR SURROUNDING SOIL.

**FLEXAMAT<sup>®</sup>**  
**REINFORCED SUBGRADE LOW WATER CROSSING (NTS)**

