



**CONSTRUCTION NOTES:**

1. AN AUTHORIZED MANUFACTURER'S REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. GRADE THE SITE SO THAT WATER WILL NOT FLOW ABOVE, BELOW, OR AROUND THE OUTSIDE OF THE AREA PROTECTED WITH FLEXAMAT. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. PRIOR TO FLEXAMAT PLUS INSTALLATION, SEED SUBGRADE WITH SITE SPECIFIC SEED MIX.
4. INSTALL FLEXAMAT PLUS ROLLS THAT ARE 15.5' WIDE WITH A 12" GEOGRID EXTENSION WITH A 6" PLUS UNDERLAMENT EXTENSION. INSTALL MATS SO THAT THE MATTING EXTENDS 10' PAST CREST OF EITHER SIDE SLOPE. MATS SHALL BE CONTINUOUS SECTIONS ACROSS THE THE CHANNEL, INCLUDING AREAS PAST CRESTS OF SIDE SLOPES. OUTSIDE EDGES OF MATS SHALL BE EMBEDDED IN AN 18" ANCHOR TRENCH. INSTALL UPSTREAM MATS OVER THE GEOGRID EXTENSION OF DOWNSTREAM MATS.
5. INSTALL 18" U-ANCHORS OR STAINLESS STEEL ZIP TIES IN 2' INCREMENTS ACROSS MATS OVERLAP SEAMS. STAINLESS STEEL ZIP TIE SHALL PENETRATE A MINIMUM OF THREE CORDS OF GRID OF EITHER MAT AT OVERLAPS.
6. AT THE BEGINNING AND END OF THE ARMORED CHANNEL, EMBED THE MAT 18" IN A TERMINATION TRENCH. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOIL.

**FLEXAMAT INFORMATION**

Manufacturer: Motz Enterprises, Inc.  
 Product Name: Flexamat Plus  
 Address: 3153 Madison Road  
 Cincinnati, OH 45209  
 Telephone: 513-772-6689  
 Email: info@Flexamat.com  
 Website: www.Flexamat.com

**FLEXAMAT CHANNEL LINING -  
 MAT LAYOUT PERPENDICULAR  
 TO CHANNEL FLOW  
 NTS**

