



**CONSTRUCTION NOTES:**

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. GRADE THE SITES SO THAT WATER WILL NOT FLOW ABOVE, BELOW, OR AROUND THE OUTSIDE OF THE AREA PROTECTED WITH FLEXAMAT. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. WHEN VEGETATION IS DESIRED, SEED AREA WITH SITE SPECIFIC SEED MIX PRIOR TO MAT INSTALLATION.
4. INSTALL FLEXAMAT ROLLS THAT ARE 15.5' WIDE WITH A 12" GEOGRID EXTENSION and 6" UNDERLAYMENT EXTENSION. INSTALL MATS SO THAT THE MATTING EXTENDS 36" PAST CREST OF SLOPE. OUTSIDE EDGES OF MATS SHALL BE EMBEDDED IN AN 18" ANCHOR TRENCH. INSTALL SUBSEQUENT MATS OVER THE GEOGRID EXTENSION OF THE PREVIOUSLY INSTALLED MAT. MATS SHALL EXTEND PAST THE TOE OF THE SLOPE A MINIMUM OF 5'.
5. INSTALL 18" U-ANCHORS OR 20" STAINLESS STEEL ZIP TIES IN 2' INCREMENTS ACROSS MAT OVERLAPS TO SECURE SEAMS. U-ANCHORS SHALL PENETRATE THROUGH THE SUBSEQUENT MATS EXTENSION OR ZIP TIES NEED TO PENETRATE 3 CORDS OF GEOGRID OF EITHER ADJACENT MAT .
6. AT THE END OF THE ARMORED SLOPE, IF HEAD CUT IS ANTICIPATED, EMBED THE MAT 18" IN A TERMINATION TRENCH. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOIL.

**FLEXAMAT INFORMATION**

Manufacturer: Motz Enterprises, Inc.  
 Product Name: Flexamat  
 Address: 3153 Madison Road  
 Cincinnati, OH 45209  
 Telephone: 513-772-6689  
 Email: info@Flexamat.com  
 Website: www.Flexamat.com

**FLEXAMAT  
 SLOPE ARMORING DETAIL  
 NTS**

