



CONSTRUCTION NOTES:

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. GRADE THE SITES SO THAT WATER WILL NOT FLOW ABOVE, BELOW, OR AROUND THE OUTSIDE OF THE AREA PROTECTED WITH FLEXAMAT. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. INSTALL 10oz NON-WOVEN GEOTEXTILE UNDERLAYMENT PRIOR TO FLEXAMAT INSTALLATION. OVERLAP GEOTEXTILE SEAMS 24".
4. INSTALL FLEXAMAT ROLLS THAT ARE 15.5' WIDE WITH A 12" GEOGRID EXTENSION. OUTSIDE EDGES OF MATS EXPOSED TO INCOMING SURFACE FLOW SHALL HAVE THE OUTSIDE TWO BLOCK UNITS RECESSED. INSTALL UPSTREAM MATS OVER THE GEOGRID EXTENSIONS OF DOWNSTREAM MATS.
5. INSTALL STAINLESS STEEL ZIP TIES IN 2' INCREMENTS ACROSS MAT OVERLAPS TO SECURE SEAMS. STAINLESS STEEL ZIP TIE SHALL PENETRATE A MINIMUM OF THREE CORDS OF GRID OF EITHER MAT AT OVERLAPS.
6. AT THE BEGINNING OF THE FLEXAMAT ARMOR, EMBED THE MATTING IN 4000 PSI CONCRETE TO TRANSITION TO CULVERT STRUCTURE.
7. AT THE END OF THE ARMORED CHANNEL, EMBED THE MAT 18" IN A TERMINATION TRENCH. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOIL.
8. INFILL THE MATTING WITH 2" OF TOPSOIL BETWEEN BLOCKS.
9. HYDROSEED OVER THE FLEXAMAT SOIL INFILL WITH NATIVE SEED.

FLEXAMAT INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flexamat
 Address: 3153 Madison Road
 Cincinnati, OH 45209
 Telephone: 513-772-6689
 Email: info@Flexamat.com
 Website: www.Flexamat.com

FLEXAMAT WITH GEOTEXTILE CHANNEL LINING NTS

