



CONSTRUCTION NOTES:

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. PRIOR TO FLEXAMAT INSTALLATION, SEED THE AREA WITH SITE SPECIFIC SEED MIX.
4. INSTALL FLEXAMAT PLUS ROLLS THAT ARE 15.5' WIDE AND INCLUDE A 12" GEOGRID AND 6" PLUS UNDERLAYMENT EXTENSION FOR OVERLAPPING MATS. THE TOP EDGE OF MAT SHALL BE RECESSED 18" INTO THE SLOPE. INSTALL SUBSEQUENT MATS OVER THE 12" GEOGRID AND 6" PLUS EXTENSION OF THE DOWNSTREAM MAT INSTALLED ADJACENT MAT. MATS SHALL BE CONTINUOUS FOR ENTIRE LENGTH OF SLOPE.
5. SECURE OVERLAP SEAMS IN 2' INCREMENTS USING 18" U-ANCHORS.
6. AT THE BEGINNING AND END OF THE LEVEE PROTECTION, EMBED THE MAT 18" PAST THE ANTICIPATED SCOUR POINT. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOIL.
7. EXTEND FLEXAMAT 5' PAST TOE OR TRENCH MAT 18" AT TOE.

FLEXAMAT INFORMATION

Manufacturer: Motz Enterprises, Inc.
 Product Name: Flexamat
 Address: 3153 Madison Road
 Cincinnati, OH 45209
 Telephone: 513-772-6689
 Email: info@Flexamat.com
 Website: www.Flexamat.com

FLEXAMAT LEVEE ARMORING DETAILS

