



**CONSTRUCTION NOTES:**

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. ALL SUBGRADE SURFACES PREPARED FOR PLACEMENT OF MATS SHALL BE SMOOTH AND FREE OF ALL ROCKS, STICKS, ROOTS, OTHER PROTRUSIONS, OR DEBRIS OF ANY KIND.
3. PRIOR TO FLEXAMAT INSTALLATION, SEED THE AREA WITH SITE SPECIFIC SEED MIX.
4. INSTALL FLEXAMAT PLUS ROLLS THAT ARE 15.5' WIDE AND INCLUDE A 12" GEOGRID AND 6" PLUS UNDERLAYMENT EXTENSION FOR OVERLAPPING MATS. THE TOP EDGE OF MAT SHALL BE RECESSED 18" INTO THE SLOPE. INSTALL SUBSEQUENT MATS OVER THE 12" GEOGRID AND 6" PLUS EXTENSION OF THE DOWNSTREAM MAT INSTALLED ADJACENT MAT. MATS SHALL BE CONTINUOUS FOR ENTIRE LENGTH OF SLOPE.
5. SECURE OVERLAP SEAMS IN 2' INCREMENTS USING 18" U-ANCHORS.
6. AT THE BEGINNING AND END OF THE LEVEE PROTECTION, EMBED THE MAT 18" PAST THE ANTICIPATED SCOUR POINT. FILL AND COMPACT TERMINATION TRENCH WITH COHESIVE SOIL.
7. EXTEND FLEXAMAT 5' BELOW ORDINARY POOL ELEVATION.

**FLEXAMAT INFORMATION**

Manufacturer: Motz Enterprises, Inc.  
 Product Name: Flexamat  
 Address: 3153 Madison Road  
 Cincinnati, OH 45209  
 Telephone: 513-772-6689  
 Email: info@Flexamat.com  
 Website: www.Flexamat.com

# FLEXAMAT WAVE IMPACT SHORELINE ARMORING DETAIL NTS

