


INSTALL STAINLESS STEEL ZIP TIES BETWEEN EVERY BLOCK. ZIP TIES SHALL ENCOMPASS 3 CORDS OF GEOGRID ON EACH SIDE OF THE SEAM.

12" MINIMUM

UNDERLAYMENT, EVENLY SPACED UNDER SEAM, MINIMUM OF 12" UNDER EACH MAT

OPTIONAL STONE INFILL, USE 10oz NON-WOVEN GEOTEXTILE UNDERLAYMENT



EDGING OR CONCRETE HEADER AS REQUIRED

FLEXAMAT PLUS

SEED, PLUG, OR SPRIG PLANTING

FINISHED GRADE AT PERIMETER

BEDDING COURSE: INSTALL 2" OF TOPSOIL

FOR CLAY OR GRANULAR SOILS, A GEOTEXTILE SEPARATION FILTER FABRIC BETWEEN SUBGRADE AND BASE IS RECOMMENDED

INFILL MAT WITH TOPSOIL TO TOP OF FLEXAMAT BLOCK

COMPACTED BASE

FLEXAMAT - DRIVABLE SURFACE INSTALLATION DETAIL

SUBGRADE THICKNESS OF CRUSHED STONE

SITE SOIL TYPE	LIGHT LOAD VEHICLES: CARS/PICKUP TRUCKS	HEAVY LOAD VEHICLES: LARGE TRUCKS, RV'S, DELIVERY VEHICLES
GRAVEL AND SAND, COURSE WELL DRAINED SOILS	BASE: 3.5-7.5" OF CRUSHED STONE	BASE: 7.5" OF CRUSHED STONE
SILTY SOILS, FINE GRAIN SOILS, POOR DRAINAGE	BASE: 7.5" OF CRUSHED STONE	BASE: 9.5" OF CRUSHED STONE
CLAY SOILS FINE TO VERY FINE	BASE: 6-9.5" OF CRUSHED STONE	BASE: 10" OF CRUSHED STONE

*ROLLS AVAILABLE IN STANDARD WIDTHS: 4', 5.5', 8', 10', 12', 16', AND 15.5' WITH 6' PLUS EXTENSION AND 12" GEOGRID EXTENSION FOR ABUTMENTS

MOTZ ENTERPRISES, INC.

Flexamat

Telephone: (513)772-6689

Email: Info@Flexamat.com

Webstie: Flexamat.com

