



## METHOD FOR TREATING EDGES EXPOSED TO FLOW



## ABUTMENT METHOD FOR SEAMS PERPENDICULAR WITH FLOW



## FLEXAMAT 10NW - STREAM & RIVERBANK MAT LAYOUT PERPENDICULAR WITH FLOW

### CONSTRUCTION NOTES:

1. AN ENGINEER OR MANUFACTURERS REPRESENTATIVE SHALL BE ONSITE FOR THE START OF THE INSTALLATION.
2. THE STREAM OR RIVERBANK MUST BE STABLE, UNIFORMLY GRADED, FREE OF ROCKS, ROOTS, AND OTHER DEBRIS.
3. FLEXAMAT 10oz. NON-WOVEN ARMOR SHALL BE CONTINUOUS THE ENTIRE LENGTH OF SLOPE. FOR SLOPES LESS THAN 16' (INCLUDING ANCHOR TRENCHES) SEE STREAM AND RIVERBANK MAT LAYOUT PARALLEL TO FLOW.
4. INSTALL 16' WIDE MATS PERPENDICULAR TO FLOW. ROLLS CAN BE PROVIDED IN CUSTOM LENGTHS IN 1' INCREMENTS.
  - 4.1. FLEXAMAT 10NW INSTALLATION WILL START AT THE DOWNSTEAM END OF THE INSTALLATION AREA AND MOVE TOWARDS THE UPSTREAM END OF THE INSTALLATION.
  - 4.2. THE INITIAL LEADING AND ENDING EDGES OF FLEXAMAT SHALL BE EMBEDDED 24" VERTICALLY BEYOND THE ANTICIPATED SCOUR POINT. THE ANCHOR TRENCH SHALL BE FILLED AND COMPACTED WITH SUITABLE FILL OR OTHER (AS SPECIFIED BY EOR).
  - 4.3. FOR ADDITIONAL SECTIONS OF MAT, THE UPSTREAM MAT SHALL BE INSTALLED OVER THE GEOGRID AND GEOTEXTILE EXTENSIONS OF THE DOWNSTEAM MATS. ENSURE THE GEOGRID AND GEOTEXTILE EXTENSIONS ARE LAYING FLAT ON THE SUBGRADE BEFORE INSTALLING UPSTREAM MAT OVER THE EXTENSIONS.
5. INSTALL 20" STAINLESS STEEL ZIP TIES IN 1' INCREMENTS ACROSS THE GEOGRID AND GEOGRID EXTENSION ABUTMENT SEAM.
6. AT THE TOE OF SLOPE OF THE ARMORED STREAM BANK, EMBED THE MAT 18" PAST THE ANTICIPATED SCOUR POINT IN AN ANCHOR TRENCH. THE TRENCH SHALL BE FILLED AND COMPACTED WITH SUITABLE FILL OR OTHER (AS SPECIFIED BY EOR).
7. OPTIONAL: MAT MAY BE INFILLED WITH SOIL OR AGGREGATE.

**MOTZ  
ENTERPRISES, INC.**

Flexamat

(513)772-6689

Info@Flexamat.com

Flexamat.com

